

**REPLACEMENT GASKETS
INSTALLATION INSTRUCTIONS
AMC JEEP MULTIPOINT FUEL INJECTION
4.0L ENGINES**

SPECIAL INFORMATION

CAUTION - Verify fuel rail assembly is depressurized by removing fuel tank cap and releasing pressure from fuel system at pressure relief valve on fuel rail assembly.

NOTE: If scraping is necessary to remove old gaskets, be careful not to damage gasket surface. Abrasive pads or wire brushes are not recommended. Spray gasket release agent (Permatex Part #4MA) is recommended. (Some replacement gaskets have adhesive backing to assist you when installed.)

O-RINGS - Lubricate with light oil (never use silicone grease, it will clog the injector).

FUEL RAIL- When servicing the fuel rail assembly precautions must be taken to prevent dirt and other contaminants from entering fuel passages.